




Helicopter Maintenance Trainer

Overview Brochure

Pennant



Introduction

The Helicopter Maintenance Trainer is a freestanding helicopter trainer enabling students to carry out practical training by performing standard maintenance procedures associated with rotary wing aircraft. There are a multitude of systems which the students can carry out functional testing, fault diagnosis and remove/install procedures.

The Helicopter Maintenance Trainer uses an optimum mix of high-fidelity replica and real aircraft components installed in a refurbished airframe representative of a generic rotary wing aircraft. The equipment enhances the training given by allowing the instructor to demonstrate at ground level, operation of systems e.g. cockpit layout, instrumentation, Gas Turbine Engine remove and install, flying controls etc. thereby underpinning the students' knowledge of these systems.



www.pennantplc.com

Contact: sales@pennantplc.com



Key Features

- Airframe structure with easily visible cockpit area
- Gas Turbine Engine
- Main Rotor and Tail Rotor Transmission
- Rotors flight control system, with collective, cyclic and yaw channels visible during operation
- Hydraulic power supply providing flight control via hydraulic assisted servo actuators
- Electrical supplies
- Generic glass cockpit featuring electronic flight instrument display
- Replicated stand by analogue flight instruments
- Students perform practical tasks using aircraft manuals, standard tools and test equipment
- Instructor operating station provides overall control, monitors activity and input of faults during simulated engine and rotor start training tasks
- Includes Ground Support Equipment and Specialist tools





Aviation Regulations Alignment

EASA/EMAR PT 66	FAA	City & Guilds	MEA UNITS
Module 6 Materials & hardware	ATA 05 Periodic Inspections	2675-01 City & Guilds Level 2 Certificate in Aircraft Maintenance (Military Aircraft) Units 104, 105, 106	Common core units MEA103, 107, 118, 151, 155 & 157
Module 7 Maintenance practices	ATA 07 Lifting & shoring		MEA202 Remove and install basic aircraft electrical system components
Module 10 Aviation legislation	ATA 09 Towing and Taxiing	2675-02, 23 Level 2 Diploma in Aircraft Engineering: Unit 003, 102	MEA203 Remove and install advanced aircraft electrical system components
Module 11 Aeroplane, aerodynamics, structures and systems	ATA 12 Servicing Routine Maintenance	2675-03 Level 3 Diploma in Aircraft Maintenance (Military/ Civil) Aircraft Mechanical/ Avionics: Units 202, 204, 205, 206, 210, 216, 217	MEA206 Remove and install aircraft basic radio communication and navigation system components
Module 12 Helicopter aerodynamics, structures and systems	ATA 24 Electrical power		MEA210 Inspect, test and troubleshoot basic aircraft electrical systems and components
Module 13 Aircraft aerodynamics, structures and systems	ATA 25 Equipment / Furnishings	2675-05 Level 3 Diploma in Aircraft Maintenance (Civil Aircraft Mechanical): Units 204, 205, 206, 216 & 217	MEA223 Inspect aircraft electrical systems and components
Module 14 Propulsion systems	ATA 27 Flight controls		MEA227 Test and troubleshoot aircraft electrical systems and components
Module 15 Gas turbine engine	ATA 28 Fuel	4608-50 Level 2 Diploma in Aerospace and Aviation Engineering (Military Foundation Competence): Units 201, 202, 203 & 240, 258, 266 & 267	MEA301 Perform aircraft flight servicing
	ATA 29 Hydraulic Power		MEA304 Remove and install non-pressurised aircraft structural and non-structural components
	ATA 43 Tactical Communications	4608-60 Level 3 Diploma in Aviation Maintenance (Military Development Competence) Core Units 301, 302, 304 455 Plus – 357, 360, 368, 379, 381, 385, 386, 389, 390, 391, 392 & 395	MEA306 Remove and install engines and engine system components
	ATA 52 Doors		MEA308 Remove and install rotary wing rotor and flight control system components
	ATA 62 Main Rotor(s)		MEA316 Inspect, test and troubleshoot rotary wing rotor and control systems and components
	ATA 63 Main Rotor drive(s)		MEA319 Inspect gas turbine engine systems and components
	ATA 64 Tail rotor		MEA330 Maintain aircraft non-primary structural removable components or parts and internal fittings
	ATA 65 Tail rotor drive		MEA346 Perform scheduled line maintenance activities on gas turbine engine rotary wing aircraft
	ATA 67 Rotors flight control		MEA352 Maintain basic rotary wing aircraft systems
	ATA 70 Standard practices - Engine		MEA398 Remove and install aircraft hydro-mechanical and landing gear system components
	ATA 71 Power plant		
	ATA 77 Engine Indicating		




Physical Specifications

PARTICULAR	VALUE	UNIT
AIRFRAME		
Length	12000	mm
Width	2100 ^{Note 1}	mm
Height	3200	mm
Weight	1000	Kg
INSTRUCTOR OPERATING STATION		
Length	1650	mm
Width	1028	mm
Height	1594	mm
Weight	230	Kg
Note ¹ : Main airframe, not including blades or access staging (10500mm rotor disc diameter)		

Supplied Documentation

Operational Manual
Maintenance Manual
Student Manual (Technical Publications)





Supported Training

SYSTEM	PRACTICAL TASK	SIMULATED FAULTS
(00) AIR VEHICLE GENERAL	1. Inspect Flying Control System	No Faults
(07) LIFTING, SHORING, RECOVERING & TRANSPORTING	1. Jack Aircraft	No Faults
(09) TOWING AND TAXIING	1. Ground handling equipment Remove and Install	No Faults
(12) SERVICING	1. Zonal Inspections (Zone 1) 2. Defuel Aircraft (Simulated) 3. Zonal Inspections (Zone 2) 4. Refuel Aircraft (Simulated) 5. Zonal Inspections (Zone 3) 6. Hydraulic Ground Power Unit connect / disconnect 7. Hydraulic system replenishment 8. Zonal Inspections (Zone 4) 9. Zonal Inspections (Zone 5)	No Faults
(24) ELECTRICAL POWER	1. Battery Remove and Install 2. External ground power connect / disconnect (Simulated) 3. Alternator Remove and Install 4. Starter generator Remove and Install	1. Battery contactor, relay not energised; 2. Generator failure, no output voltage; 3. Alternator failure, no voltage output
(25) EQUIPMENT AND FURNISHINGS	1. Pilot seat Remove and Install 2. Heating duct and cover Remove and Install	No Faults



Supported Training

SYSTEM	PRACTICAL TASK	SIMULATED FAULTS
(27) FLIGHT CONTROLS	1. Tail Rotor servo Remove and Install	No Faults
(28) FUEL	1. Fuel Pump Remove and Install 2. Fuel cut off valve control Remove and Install 3. Fuel filter baffle Remove and Install 4. Fuel filter element Remove and Install	1. Boost pump failure; 2. Partial filter blockage; 3. Complete filter blockage, bypass valve operated
(29) HYDRAULIC POWER	1. Tail Rotor controls adjust 2. Basic rigging check	1. Hydraulic pump fails to operate
(43) TACTICAL COMMUNICATIONS	1. ARC 340 homer aerials Remove and Install	No Faults
(52) DOORS	1. Cabin door Remove and Install 2. Main Rotor Gearbox Cowling Remove and Install 3. Engine cowling Remove and Install	No Faults
(62) MAIN ROTORS	1. Main rotor blade examination 2. Main rotor blade Remove and Install 3. Damper Remove and Install 4. Main Rotor Head examination 5. Main Rotor Head Remove and Install 6. Pitch Change Link Remove and Install 7. Non-rotating scissor check Torque	No Faults
(63) MAIN ROTOR DRIVES	1. Clutch and freewheel assembly Remove and Install 2. Main Rotor Gearbox examination 3. Torque transmitter Remove and Install 4. Main Rotor Gearbox Remove and Install 5. Main Rotor Gearbox and Main Rotor Head Remove and Install 6. Magnetic Plug inspection 7. Rotor brake adjustment 8. Rotor brake examination	1. Torque liaison sensor Detection Failure; 2. Clutch Failure
(64) TAIL ROTOR	1. Tail Rotor Head Remove and Install 2. Tail Rotor Gearbox Remove and Install 3. Tail Rotor Head and gearbox examination 4. Tail Rotor Head Remove and Install	No Faults
(65) TAIL ROTOR DRIVE	1. Tail Rotor Drives and Intermediate Gearbox Examination 2. Inclined drive shaft Remove and Install 3. Horizontal drive shaft Remove and Install 4. Connecting shaft Remove and Install 5. Intermediate gearbox Remove and Install	No Faults
(67) ROTORS FLIGHT CONTROL	1. Tail Rotor controls adjust 2. Basic rigging check	No Faults
(70) STANDARD PRACTICES - ENGINE	1. Engine Remove and Install	No Faults
(71) POWER PLANT	1. Ground Run (Simulated)	No Faults



Optional Accessories

Spares Kit

Ordering Information

99301-000-0001A	Basic Maintenance Helicopter Trainer
99301-3021	Spares Kit



